



ANYWAVE



MSP
Multi-Stream Processor
User Manual

Version 1.6

TSP-EAS-1

May 10, 2017



Copyright Notice

Copyright © Anywave Communication Technologies, Inc. 2015, All rights reserved.
No part of this publication may be reproduced, translated, transcribed, stored in a retrieval system, or transmitted into any form or by any means, without the express written permission of Anywave Communication Technologies, Inc.

Disclaimer

Information provided by Anywave Communication Technologies is believed to be accurate and complete; however, no liability can be assumed for its use. The information contained in this publication is subject to change without notice.

Anywave Communication Technologies Inc.
300 Knightsbridge Parkway, Suite 150, Lincolnshire, IL 60069
Tel: +1 (847) 415-2258
Fax: +1 (847) 415-2112
<http://www.anywavecom.com/en/>



Contents

1 Product Appearance	4
1.1 Front Panel	4
1.2 Back Panel	5
2 Operation Specifications	6
3 Menu	8
3.1 Initialization	8
3.2 Query Mode	8
3.3 User Menu	10
3.4 Advanced Menu	13
3.4 Management GUI Software	14
4 Connection	23
4.1 Connect the MSP	23
4.2 Connect and activate the EAS	23
5 Troubleshooting	24
5.1 ASI Input	24
5.2 CVBS Input	24
5.3 SDI Input	24
5.4 SDI Output	24
5.5 ASI Output	24
5.5 DPSIP	25
6 Dynamic PSIP module (optional)	26
6.1 Network	26
6.2 System	28
6.3 Update	28
6.4 Log	28
6.5 PSIP Generator	29



1 Product Appearance

1.1 Front Panel



LCD:

40×2 LCD with power saving backlight

6 Buttons:

Left, Right, Up, Down, OK, ESC

6 LEDs:

IN1: When illuminated, CVBS IN1 or SDI IN1 is connected. When flashing, EAS is triggered.

IN2: When illuminated, CVBS IN2 or SDI IN2 is connected. When flashing, EAS is triggered.

IN3: When illuminated, CVBS IN3 or SDI IN3 is connected. When flashing, EAS is triggered.

IN4: When illuminated, CVBS IN4 or SDI IN4 is connected. When flashing, EAS is triggered.

STAT: Constant on indicates no PSIP data detected when under dynamic PSIP mode. Flashing indicates PSIP overflow.

ERR: Constant on indicates there is no ASI input detected. Flashing indicates the output TS overflow.

1 RJ45 connector:

PSIP: RJ45 port for remote control of Dynamic PSIP module and PSIP service data ingestion.



1.2 Back Panel



SDI IN 1:	Serial digital interface input #1
SDI IN 2:	Serial digital interface input #2
SDI IN 3:	Serial digital interface input #3
SDI IN 4:	Serial digital interface input #4
CVBS 1:	Composite video and stereo audio input #1
CVBS 2:	Composite video and stereo audio input #2
CVBS 3:	Composite video and stereo audio input #3
CVBS 4:	Composite video and stereo audio input #4
SDI OUT 1:	Serial digital interface output #1
SDI OUT 2:	Serial digital interface output #2
SDI OUT 3:	Serial digital interface output #3
SDI OUT 4:	Serial digital interface output #4
EAS IN:	Composite video and stereo audio input for EAS signal
EAS LOOP OUT:	Loop out of EAS IN
EAS CTRL IN:	EAS trigger control input
EAS CTRL OUT:	Loop out of EAS CTRL IN
ASI IN 1:	ASI input #1
ASI IN 2:	ASI input #2
ASI IN 3:	ASI input #3
ASI IN 4:	ASI input #4
ASI OUT 1:	ASI output #1
ASI OUT 2:	ASI output #2, repeated output of ASI OUT 1
REMOTE:	RJ45 port for remote management



2 Operation Specifications

- Environment
 - Operating Temperature: -10 ~ 50 °C
 - Operating Humidity: ≤ 95%
 - Atmospheric Pressure: 86 kPa ~ 106 kPa
- Power Supply
 - Voltage: 88 ~ 264 VAC
 - Frequency: 50 / 60 Hz
- Inputs/Outputs
 - CVBS IN 1/2/3/4 Composite video(yellow) and stereo audio(white and red)
 - ◆ Connector: RCA female
 - ◆ Impedance: 75 Ω
 - ◆ Location: Back Panel
 - SDI IN 1/2/3/4 HD/SD Serial digital interface for uncompressed digital video/audio
 - ◆ Connector: BNC female
 - ◆ Impedance: 75 Ω
 - ◆ Location: Back Panel
 - SDI OUT 1/2/3/4 Serial digital interface for uncompressed digital video/audio
 - ◆ Connector: BNC female
 - ◆ Impedance: 75 Ω
 - ◆ Location: Back Panel
 - EAS IN Composite video/audio for EAS input
 - ◆ Connector: RCA female
 - ◆ Impedance: 75 Ω
 - ◆ Location: Back Panel
 - EAS OUT (loop out of EAS IN)
 - ◆ Connector: RCA female
 - ◆ Impedance: 75 Ω
 - ◆ Location: Back Panel
 - EAS CTRL IN EAS trigger control
 - ◆ Connector: 6-pin slot
 - ◆ Voltage: 5 VDC
 - ◆ Location: Back Panel
 - EAS CTRL OUT (loop out of EAS CTRL IN)
 - ◆ Connector: 6-pin slot
 - ◆ Location: Back Panel
 - ASI IN 1/2/3/4
 - ◆ Connector: BNC female
 - ◆ Impedance: 75 Ω
 - ◆ Level: See Table 1



- ◆ Location: Back Panel
- ASI OUT 1/2
 - ◆ Connector: BNC female
 - ◆ Impedance: 75 Ω
 - ◆ Location: Back Panel

Table 1 ASI Input Specifications

No	Content	Unit	Value
1	Input Level	mv	≥ 200
2	Positive Transition (20%~80%)	ps	≤ 1200
3	Negative Transition (20%~80%)	ps	≤ 1200
4	Deterministic Jitter	%	≤ 10
5	Random Jitter	%	≤ 8

Note

- 1) The electrical interface characteristics are measured under normal conditions. Values may vary.
- 2) Operating in abnormal conditions may result in damage to the equipment. Long operating hours in severe environments may reduce the reliability of the entire system, which may cause permanent damage to equipment. Make sure all electrical interface characteristics and environmental parameters are within the defined range listed above before operating this equipment.



3 Menu

3.1 Initialization

Connect the power supply of the unit and then turn on the MSP via the power switch located on the rear panel. The initialization process takes about 10 seconds to finish for the main unit and about 30 seconds to finish for the (optional) dynamic PSIP module.

The MSP incorporates a Dynamic PSIP Generator and Inserter, has 4 HD/SD SDI inputs, converts and switches 4 CVBS inputs into 4 SDI outputs, supports 4 ASI inputs into an onboard Multiplexor with program cherry-picking into 2 ASI outputs, and manages EAS control signals and switching. The module provides manual switching between the 4 incoming SDI inputs and 4 converted SDI signals from CVBS sources, with automatic EAS switching of EAS signal, which overrides all manual settings when an EAS trigger occurs.

The first step after turning on the unit is to confirm the desired input source (for video/audio, ASI in, PSIP etc.). Please see Table 2~5 below for details.

3.2 Query Mode

Query mode is a mode which displays parameters and status of the MSP. There are five pages in query mode. Press the "Right" or "Left" button to switch between different pages which are shown in Table 2 through 6 below.

Note: The settings shown in the tables below are for illustration purposes only and may be different from those in actual use.

Table 2 First Page in Query Mode

ASIIN1	ASIIN2	ASIIN3	ASIIN4
19.390/4	10.000/2	N/A	N/A

Table 3 Second Page in Query Mode

ASIOUT1	ASIOUT2	PSIP	STATUS
4.600/2	4.600/2	Dynamic	OK

Table 4 Third Page in Query Mode

CVBS1	CVBS2	CVBS3	CVBS4
OK	ERR	OK	ERR

Table 5 Fourth Page in Query Mode

SDIIN1	SDIIN2	SDIIN3	SDIIN4
OK	ERR	OK	ERR

Table 6 Fifth Page in Query Mode

SDIOUT1	SDIOUT2	SDIOUT3	SDIOUT4	SOURCE
---------	---------	---------	---------	--------



OK	ERR	OK	ERR	CVBS
----	-----	----	-----	------

Note:

- 1) The “ASIIN” in **Error! Reference source not found.** shows the status of the ASI input. If no TS is detected and locked in the ASI input, the status shows “N/A”, if TS is detected and locked in the ASI input, the status will alternate between the TS actual rate(Mb/s) and the number of programs in the TS.
- 2) The “ASIOUT” in **Error! Reference source not found.**3 shows the status of the ASI output. If no TS is present in the ASI output, the status shows “N/A”, if TS is present in the ASI output, the status will alternate between the TS’s payload rate(Mb/s) and the number of programs in the TS.
- 3) The “PSIP” in Table 3 shows where the PSIP data comes from, “Static” means using the MUX’s built in static PSIP, “Dynamic” means PSIP data comes from the Dynamic PSIP module, “Disable” means PSIP insertion is disabled. “STATUS” only takes effect when the PSIP data source is “Dynamic”, “OK” means the PSIP data is detected and inserted by MUX, “ERR” means no PSIP data detected

The "CVBS" status in

ASIOUT1	ASIOUT2	PSIP	STATUS
4.600/2	4.600/2	Dynamic	OK

- 4) Table 4 indicates if the composite video signal is detected at the corresponding CVBS input. “OK” means signal detected, “ERR” means no signal detected.

The "SDIIN" status in

ASIOUT1	ASIOUT2	PSIP	STATUS
4.600/2	4.600/2	Dynamic	OK

- 5) Table 45 indicates if signal is detected at the corresponding SDI input. “OK” means signal detected, “ERR” means no signal detected.
- 6) The “SDIOUT” status in Table 6 indicates if the particular SDI output is active. “OK” means active, “ERR” means inactive
- 7) The “SOURCE” in Table 6 shows where the SDI output signal source comes from, “CVBS” means it’s converted from CVBS input, “SDI” means it’s from SDI input, “EAS” means it’s from EAS signal



3.3 User Menu

In Control mode, the user may modify configuration settings of the MSP. There are two levels of control, the User Menu and the Advanced Menu. To enter the User Menu, press **both** the "Left" and "Right" buttons **at the same time** while in query mode. The User Menu in control mode is shown below in Table 7. In the next section we will present the Advanced Menu.

Table 7 Main Menu

Welcome to setting interface!			
*MUX_IN	MUX_OUT	SDI_OUT	CONFIG

The Main User Menu consists of 5 sub-menus: MUX_IN, MUX_OUT, SDI_OUT, CONFIG and PSIP.

Once at the main menu, press the "Left" or "Right" buttons to move the cursor and navigate to the desired sub-menu. Once the cursor is positioned just above the desired sub-menu, press the "OK" button to enter the target sub-menu. When in the corresponding sub-menu, press "Left" or "Right" button to move the cursor to the target parameter and then press the "Up" or "Down" buttons to select different options from the drop-down boxes. Once you have selected the desired option, **press the "OK" button to apply and save, or press the "ESC" button to skip the changes and return to the upper menu.**

All the parameters of sub-menus are shown in Tables 8 through Table 13 respectively.

Table 8 MUX_IN Menu

	*ASI_IN1	ASI_IN2	ASI_IN3	ASI_in4
--	----------	---------	---------	---------

Press "OK" to enter ASI_IN sub-menu

Table 9 ASI_IN sub-menu

	*Channel	Sht_name	Maj_num	Min_num
Default	1	AW-TV1	005	001
Options	1	AW-TV1	005	001
	2	AT-TV2	005	002

Note:

- 1) The MUX_IN menu provides ASI input stream status only. The ASI_IN sub-menu displays the program information found in the particular ASI input. "Channel" displays the program number, use the "Up" or "Down" buttons to browse the entire program list. "Sht_name" displays the short name, "Maj_num" displays the major channel number, and "Min_num" displays the minor channel number. This status information is only available when valid PSIP information is present in the ASI input TS.



- 2) If there is no TS detected and locked on a particular ASI input, ASI_IN sub menu will show “NULL”

Table 10 MUX_OUT Menu

	CTRL	PSIP_BW	TS_RATE	PROGRAM
Default	Static	500kb	19.390Mb	(see PROGRAM sub-menu)
Options	Static			
	Dynamic			
	Disable			

Note:

- 1) The CTRL parameter sets the PSIP source, option “Static” means insert PSIP using MUX’s built-in static PSIP, “Dynamic” means insert PSIP from Dynamic PSIP module, “Disable” means disable PSIP insertion.
- 2) PSIP_BW parameter specifies the PSIP overhead bandwidth in output TS.
- 3) TS_RATE parameter specifies the output TS rate.

Table 11 PROGRAM Sub-Menu

	Channel	Sht_Name	Maj_Num	Min_Num
Default	1	AW-TV1	05	001
Options	1	AW-TV1	05	001
	2	AW_TV2	05	002

Note:

- 1) The PROGRAM Sub menu specifies the static PSIP information of the output TS, these settings only take effect when “CTRL” is set to “Static”.
- 2) Move cursor to “Channel” and press “UP” or “DOWN” button to browse program list.
- 3) Move cursor to “Sht_Name”, “Maj_Num” and “Min_Num” and then press “UP” or “DOWN” to select the desired alpha-numeric character.

Table 12 SDI_OUT Menu

	*SOURCE1	SOURCE2	SOURCE3	SOURCE4
Default Value	AUTO	AUTO	AUTO	AUTO
Options/Values	AUTO	AUTO	AUTO	AUTO
	CVBS	CVBS	CVBS	CVBS
	SDI	SDI	SDI	SDI
	EAS	EAS	EAS	EAS

Note:

- 1) "SOURCE#" selects where the source of each SDI_OUT comes from, they can be configured separately.



- 2) If select option “AUTO”, MSP will first search signals from CVBS input and convert to SDI output, if no signal detected, MSP will then search signals from SDI input and convert to SDI output.
- 3) If select option “CVBS”, MSP will always search signals from CVBS input and ignore signal from SDI input.
- 4) If select option “SDI”, MSP will always search signal from SDI input and ignore signal from SDI input.
- 5) When EAS signal is triggered, SDI output will switch to EAS signal as source.
- 6) If select option “EAS”, SDI output will always use EAS signal as the source of SDI output.

Table 13 CONFIG Menu

	IP	GATEWAY	MASK	UPGRADE	VER
Default	192.168.001.1 90	192.168.001.0 01	255.255.255.0 00	NO	
Options	***.***.***.* **	***.***.***.* **	***.***.***.* **	NO	
				YES	

Note:

- 1) "IP", "GATEWAY", and "MASK" are used to establish a valid Ethernet connection for remote control via the REMOTE RJ45 located on the rear panel. The MSP has a control GUI program that is running on Windows PC. Simply by connecting the PC to MSP and invoke the control program, you can configure the MSP remotely.
- 2) "UPGRADE" is a reserved mode to perform an upgrade of the code inside the MSP unit.
- 3) “VER” shows the information of MSP’s current version.



3.4 Advanced Menu

To enter the Advanced Menu, first enter the User Menu by pressing both the *"Left"* and *"Right"* buttons at the same time to arrive at the menu shown below.

Table 14 User Menu

Welcome to setting interface!			
*MUX_IN	MUX_OUT	SDI_OUT	CONFIG

Then, press both the *"Up"* and *"Down"* buttons at the same to enter Advanced Menu, as shown below.

Table 15 Advanced User Menu

Welcome to advanced interface!					
*SN	PSIP				

Table 16 shows the corresponding sub-menus.

Table 16 SN Menu

	SN	PSIP_KEY	MAC
Default	99999999999999	FFFFFFFF	99999999999999

Note:

- 1) "SN" shows the serial number of this unit.
- 2) "PSIP_KEY", MSP needs a valid KEY to enable static PSIP feature, please contact Anywave to obtain a valid KEY.
- 3) "MAC" shows the mac address of the RJ45 management port.

Table 17 PSIP Menu

	IP	GATEWAY	MASK
Default	192.168.225.1 91	192.168.225.0 01	255.255.255.000
Options	***.***.***.* **	***.***.***.* **	***.***.***.***

Note:

- 4) MSP takes dynamic PSIP data from dynamic PSIP module via the internal Ethernet port, those settings are only for debug purpose.
- 5) DO NOT change the values in PSIP Menu.




3.4 Management GUI Software

The MSP uses a Management software interface to accommodate remote control and monitoring via the rear port REMOTE RJ-45 connection. Once you network the MSP with your PC and login to the interface, you can configuration and monitor the status of the MSP via the Management software. The Management software can configure multiple units within the same program, the default IP of the MSP is 192.168.1.190.


Click the executable “msp_GUI Vx.x.x.exe” to launch the program (Note this executable is only Windows compatible), you will see the login window.




Enter UserName: admin and Password: admin and click “Login” to enter the main screen



Click “Edit” -> “Add Branch” to add a Branch



Click the branch you created and click “Edit” -> “Add Equipment” to add a MSP




Click on the MSP name created to start configuration and view the status of this particular MSP.

There are 4 tabs across the left top of the window:

- **Input:** Configure the multiplexor, select programs, change PID, edit static PSIP, etc.
- **Output:** Configure the TS rate, PSIP source, and source of SDI output
- **Config:** Change the network settings
- **Status:** View the status of the MSP

Input





There are 2 sub-tabs under Input: MUX and TS.

- MUX

After any of the 4 ASI inputs are connected and a valid TS is present, you can choose (cherry pick) which programs are to be multiplexed into the output ASI TS, MSP supports up to 8 programs to be selected into the output ASI TS.

- “PID Remapping”

Choose if to do PID remapping during multiplexing, default value is YES

- “Refresh Input”

Click to refresh the ASI input status, click this button when ASI input connection change.

- “Refresh output”

Click to refresh the ASI output status

- “---->”

You can expand the treeview to browse the programs of the 4 ASI inputs (the left window), check the boxes of the programs you want multiplexed into the output ASI TS, and then click this right arrow button to add these programs into the output TS.

- “<----”

Check the boxes of the programs in the left window and click this left arrow button to remove them from output TS.

On the bottom of the right window, you can see how many programs have been selected for the output TS multiplex, and the payload/TS rate of output TS. Also there is a TS output overflow indicator.



- TS

Input Output Config Status

Mux TS

PAT/PMT
Channel TS ID(Hex) 248D

Index	Prog Num	PMT PID	PCR PID	ELM1 Type	ELM1 PID	ELM2 Type	ELM2 PID	ELM3 Type	ELM3 PID	ELM4 Type	ELM4 PID	ELM5 Type	ELM5 PID
1	1	0x0030	0x0066	Video(0x02)	0x0031	Audio(0x81)	0x0034	NULL	NULL	NULL	NULL	NULL	NULL
2	2	0x0040	0x0067	Video(0x02)	0x0041	Audio(0x81)	0x0044	NULL	NULL	NULL	NULL	NULL	NULL
3	3	0x0050	0x0068	Video(0x02)	0x0051	Audio(0x81)	0x0054	NULL	NULL	NULL	NULL	NULL	NULL

PSIP
Modulation Mode 4 Carrier Frequency(Hz) 0 VCT ID: TVCT

Index	Prog Num	Short Name	Major Num	Minor Num
1	1	AW-TV1	1	1
2	2	AW-TV2	1	2
3	3	AW-TV3	1	3

Get Set

- In “PAT/PMT” table, you can define the program_number (Prog Num), PCR_PID, and element_PID (ELM PID) by double clicking the entry of each stream.
 - Either hex (start with 0x) or decimal are allowed for entering of PIDs.
 - When PCR PID share the same PID as the element_PID, PCR PID could not be modified.
 - element_TYPE (ELM Type) could not be modified.
 - User could modify the element stream PID (ELM PID) of the corresponding element TYPE (ELM Type), the allowed range for ELM PID is 1 ~ 0x1ff0.
- “PSIP” table is only valid when you select PSIP source as “Static” in “Output” tab
- In “PSIP” table, you can define the Modulation Mode value, Carrier Frequency, VCT ID (TVCT or CVCT). You can also edit short_name (Short Name), major_channel_num (Major Num) and minor_channel_num (Minor Num) for each of the programs
- “Set” → Click “Set” to save the setting to MSP
- “Get” → Click “Get” to get MSP’s current setting



Output

The screenshot shows the 'Output' configuration page. At the top, there are four tabs: 'Input', 'Output', 'Config', and 'Status'. The 'Output' tab is selected. Below the tabs, there are two main sections: 'MUX OUT' and 'SDI OUT'. In the 'MUX OUT' section, there are three fields: 'TS Rate Max(Mb)' with the value '19.390', 'PSIP Bandwidth(Kb)' with the value '500', and a 'PSIP' dropdown menu set to 'Dynamic'. In the 'SDI OUT' section, there are four 'Source' dropdown menus labeled 'Source1', 'Source2', 'Source3', and 'Source4', all set to 'AUTO'. At the bottom of the page, there are two buttons: 'Get' and 'Set'.

- “TS Rate Max(Mb)”
Specify the output TS rate in Mbps
- “PSIP Bandwidth(Kb)”
Specify the Dynamic PSIP overhead in Kbps
- “PSIP” → Select the PSIP source
 - Static: use the MUX’s built-in static PSIP insertion
 - Dynamic: use the dynamic PSIP module as the PSIP source for PSIP insertion
 - Disable: disable the PSIP insertion
- “Source” → Select where the source of each SDI output comes from
 - If select option “AUTO”, MSP will first search signals from CVBS input and convert to SDI output, if no signal detected, MSP will then search signals from SDI input and connect



- to SDI output.
- If select option “CVBS”, MSP will always search signals from CVBS input and ignore signals from SDI input.
- If select option “SDI”, MSP will always search signal from SDI input and ignore signals from SDI input.
- When EAS signal is triggered, SDI output will switch to EAS signal as source.
- If select option “EAS”, SDI output will always use EAS signal as the source of SDI output.
- “Set” → Click “Set” to save the setting to MSP
- “Get” → Click “Get” to get MSP’s current setting

Config

The screenshot shows the configuration interface for the TSP-EAS-1 device. The 'Config' tab is selected, and the 'Management' section is expanded. The IP address is set to 192.168.1.191, the Gateway is 192.168.1.1, and the Mask is 255.255.255.0. There are 'Get' and 'Set' buttons for each field. A 'Restart' section at the bottom has a dropdown menu and a 'Set' button.

- “Management” → Configure the network setting of the “REMOTE” RJ45 port.
- “Slave” → Debug only, configure the internal network port for dynamic PSIP insertion, (Warning: DO NOT change these settings)
- “Set” → Click “Set” to save the setting to MSP
- “Get” → Click “Get” to get MSP’s current setting
- “Restart” → Select “YES” from the pull down menu and click “Set” to restart MSP



Status

Section	Input	Field	Value
ASI IN	1	Program Num	4
		TS Rate(Mb)	19.390
	2	Program Num	N/A
		TS Rate(Mb)	N/A
	3	Program Num	N/A
		TS Rate(Mb)	N/A
	4	Program Num	N/A
		TS Rate(Mb)	N/A
ASI OUT	1	Program Num	3
		Payload(Mb)	2.275
	2	Program Num	3
		Payload(Mb)	2.275
	PSIP	PSIP	Dynamic
	STATUS	ERR	
	Overflow	NO	
CVBS	1	Status	ERR
	2	Status	ERR
	3	Status	ERR
	4	Status	OK
SDI IN	1	Status	OK
	2	Status	OK
	3	Status	OK
	4	Status	OK
SDI OUT	1	Status	ERR
		Source	CVBS
	2	Status	ERR
		Source	CVBS
3	Status	ERR	
	Source	CVBS	
4	Status	OK	
	Source	SDI	

Get

- “Get” → Click “Get” to refresh MSP’s current status
- ASI IN
 - “Program Num” → Displays the number of programs of the particular ASI input.
 - “TS Rate (Mb)” → Displays the TS rate in Mb for the particular ASI input.
- AIS OUT
 - “Program Num” → Displays the number of programs in the ASI output.
 - “Payload (Mb)” → Displays the payload data rate in MB in ASI output.



- PSIP
 - “PSIP” → Displays the PSIP insertion source.
 - “STATUS” → Displays if MUX receives the PSIP data from dynamic PSIP module, valid only when PSIP source is Dynamic.
 - “Overflow” → Displays if the received PSIP data rate exceeds the PSIP bandwidth, valid only when PSIP source is Dynamic.
 -
- CVBS
 - “Status” → Displays if MSP detects the signal on particular CVBS input interface.
- SDI IN
 - “Status” → Displays if MSP detects the signal on particular SDI input interface.
- SDI OUT
 - “Status” → Displays if there are output signals on particular SDI out interface.
 - “Source” → Displays where the signal source of SDI output comes from.




4 Connection

4.1 Connect the MSP

- Don't turn On or Off the exciter when the transmitter is running. The correct order is:
 - Connect REMOTE and PSIP to network with RJ45 port.
 - Turn on the MSP.
 - After initialization is finished, connect the input with corresponding signal source.
 - Connect EAS input and EAS control IN to EAS generator.
 - Connect ASI output to target devices.

4.2 Connect and activate the EAS

- EAS video/audio should be connected to MSP's EAS IN CVBS ports.
- EAS activation is controlled by the 6-pin contact closure slot (EAS CTRL IN) in the back panel



From the left to right:

1st and 2nd pins are N/A

3rd pin should be provided with an external 12 volt DC power supply

4th and 5th pin are the short pin which should be connected to EAS generator.

6th pin should be connected to ground of the 12V power supply.

When 12V external DC power is provided and 4th and 5th pins are short, EAS will be activated.



5 Troubleshooting

5.1 ASI Input

- ASI Input ERROR
 - Alarm message
 - ◆ LCD: ASIIN# N/A
 - ◆ LED_ERR: Constant ON
 - Cause: Input signal to ASI input is lost or has invalid format.
 - Solution: Check the stream to make sure input signal has valid format.

5.2 CVBS Input

- CVBS Input ERROR
 - Alarm message
 - ◆ LCD: CVBS# ERR
 - Cause: Input signal to CVBS input is lost or has invalid format.
 - Solution: Check the corresponding input composite signal to make sure input signal has valid format.

5.3 SDI Input

- SDI Input ERROR
 - Alarm message
 - ◆ LCD: SDIIN# ERR
 - Cause: Input signal to SDI input is lost or has invalid format.
 - Solution: Check the corresponding SDI input to make sure input signal has valid format.

5.4 SDI Output

- SDI Output ERROR
 - Alarm message
 - ◆ LCD: SDIOUT# ERR
 - ◆ LED_IN#: OFF
 - Cause: There is no input signal detected from either CVBS or SDI
 - Solution: Check the corresponding SDI input to make sure input signal has valid format, if input signal is Ok, make sure SOURCE is selected correctly.

5.5 ASI Output

- ASI Output ERROR
 - Alarm message



- ◆ LCD: ASIOUT# N/A
- Cause: There is not valid TS in ASI input, or user has not selected a program to be muxed into the ASI output
- Solution: Check stream of ASI input, and make sure programs are selected correctly in the control GUI.
- ASI Output Overflow
- Alarm message
 - ◆ GUI: Overflow RED
- Cause: Payload exceeds the total TS rate.
- Solution: Check the selection of programs to be multiplexed, reduce the number of programs selected.

5.5 DPSIP

- DPSIP ERROR
- Alarm message
 - ◆ LCD: PSIP STATUS ERR
 - ◆ LED_STAT ON
- Cause: MUX didn't detect the input Dynamic PSIP data.
- Solution: Check the configuration of PSIP Generator, reboot Dynamic PSIP module if needed.
- DPSIP Overflow
- Alarm message
 - ◆ LED_STAT: FLASHING
 - ◆ GUI: Overflow YES
- Cause: Dynamic PSIP data rate exceeds bandwidth set for PSIP data.
- Solution: Check the PSIP Generator's output data rate, set PSIP bandwidth greater than data rate reported by PSIP Generator.



6 Dynamic PSIP module (optional)

MSP provides an optional Dynamic PSIP module, it's configured separately to the MSP. It is accessible via the front PSIP RJ-45 port. The default IP address for Dynamic PSIP module is 192.168.1.80.

Network a computer configured with static IP address 192.168.1.x to the PSIP RJ45 front panel port, launching a web browser and entering the PSIP module's IP address (192.168.1.80) will bring up following page.



6.1 Network

Click “Network” to enter network setup page.



Network	System	Update
---------	--------	--------

Data Interface (eth0) DO NOT CHANGE

DHCP
 Static

Address . . .

Mask . . .

Gateway . . .

Management Interface (eth1)

Disabled
 DHCP
 Static

Address . . .

Mask . . .

Gateway . . . **OK**

DNS

Nameserver . . . **OK**

Nameserver . . . **OK**

Nameserver . . .

Nameserver . . .

NTP

Server **OK**

Server **OK**

Server **OK**

Server **OK**

Enter host name or IP address for at least one Network Time Protocol (NTP) server.
[Reset defaults](#)

Note:

1. Network Interface (eth0) is used to configure the communication interface to MSP, DO NOT change this setting.
2. Network Interface (eth1) is the management interface for Dynamic PSIP module, please change this setting accordingly with your network setting and hit “Apply Changes” on the bottom of the page to submit the change. Please remember the setting of eth1 otherwise you will lose connection to the Dynamic PSIP module.
3. There is no need to change DNS/NTP setting, but please make sure the Dynamic PSIP module is connected correctly to the internet since it needs access to the internet for PSIP service data ingestion and network timing update (through RTC enclosed).



6.2 System

Click “Set Timezone” to set the correct time zone to the DPSIP module, click “System” if you need to reboot Dynamic PSIP module.

Network System Update

Current TimeZone: America/Chicago

Eastern Time ▼ Set Timezone

Note: System needs reboot to apply Timezone change(reboot of PSIP module will not interrupt on air signal).

Reboot System

Note:

1. If you are using Anywave txt format as the ingest service data of the PSIP generator, you must set the correct time zone to the DPSIP module, since Anywave txt is using local time. Other formats are using UTC time so correct time zone is not a must.

6.3 Update

Click “Update” to update PSIP Generator on the Dynamic PSIP module.

Network System Update

Current PSIPGenerator Ver: V1.8.2

Select file(.zip) to upload: Choose File No file chosen

Update

Warning: System will reboot after an update is performed.

Note:

1. Please only update with the original update file Anywave provided.

6.4 Log

Click “Log” to view the application log of PSIP generator.



Management Log

PSIPGenerator Log

All Messages ▾

```
Starting Server Mode... Time: 2015-07-20 10:21:17
2354@AwDPSIP pid:2354
Database Server started...
Database server initialized on eth1:192.168.1.82:1527
Host SN: B827EB740793
Info: Virtual Channels Loaded: 3
Sending psip to 192.168.225.191:11101
WARNING: period index 133093 not found in database with Source ID 1, use default program name...
WARNING: period index 133093 not found in database with Source ID 2, use default program name...
WARNING: period index 133093 not found in database with Source ID 3, use default program name...
WARNING: period index 133094 not found in database with Source ID 1, use default program name...
WARNING: period index 133094 not found in database with Source ID 2, use default program name...
WARNING: period index 133094 not found in database with Source ID 3, use default program name...
WARNING: period index 133095 not found in database with Source ID 1, use default program name...
WARNING: period index 133095 not found in database with Source ID 2, use default program name...
WARNING: period index 133095 not found in database with Source ID 3, use default program name...
WARNING: period index 133096 not found in database with Source ID 1, use default program name...
WARNING: period index 133096 not found in database with Source ID 2, use default program name...
WARNING: period index 133096 not found in database with Source ID 3, use default program name...

Current Period Start Time: 2015-07-20 10:00:00
Next Period Start Time: 2015-07-20 13:00:00

Info: Socket Server Started at 52506 ...
```

6.5 PSIP Generator

After Network is properly setup and connection to the Dynamic PSIP Module is acquired, you can use PSIP Client software to configure the PSIP Generator. Please refer to Anywave PSIP Client User Manual for the configuration of the PSIP Generator.



Anywave Communication Technologies Inc.
300 Knightsbridge Parkway, Suite 150, Lincolnshire, IL 60069
Tel: (847) 415-2258
Fax: (847) 415-2112
Email: sales_us@anywavecom.com
<http://www.anywavecom.com/en/>